

BOTH ENDS OF THE CABLE HAVE TO GO TO EITHER THE THERMOSTAT OR THE CONTACTOR, OR OTHER POWER SOURCE.


SPLICES MUST BE TOTALLY ENCASED IN SCREED.

MAINTAIN 1/2 OF RECOMMENDED CABLE SPACING BETWEEN THE CABLE AND THE WALLS OR OTHER PERMANENT STRUCTURE.


CABLE SPACING REFERS TO THE DISTANCE BETWEEN THE PARALLEL RUNS OF CABLE.

DIAMETER OF RETURN BEND MUST NEVER BE LESS THAN 2 INCHES.

MAINTAIN RECOMMENDED SPACING BETWEEN CABLE ON THE HOME RUN.



<b>Orbit Manufacturing</b>	
<b>CABLE PLACEMENT I</b>	
Drawn By: jsa	<b>ORB 20022 Rev. 0</b>




**Orbit Manufacturing**


**CABLE PLACEMENT II**

Drawn By: jsa

**ORB 20020 Rev. 0**



<b>Orbit Manufacturing</b>	
<b>CABLE PLACMENT III</b>	
Drawn By: jsa	<b>ORB 20024 Rev. 0</b>



Orbit Manufacturing

CABLE PLACEMENT EXAMPLE IV

Drawn By: jsa

ORB 20025 Rev. 0